



Operating a Toyota compatible Digital Media Player


① Setting the audio mode

Put the stereo in the changer mode by pressing the CD Changer button.


② Using the SSA/Voice Interface

The PhatBox uses the SCAN button to toggle through 4 modes

The modes are in the following order:



Note: The CD Manager (not the Music Manager) creates one "playlist" for every CD copied onto the DMS cartridge. The "Discs" shown in the CD Manager software are referred to as "playlists" in the car.



③ Navigating Mode Items

After the car stereo is set to one of the 4 modes, navigate through the list of items (playlists, artists, albums, or genres) by using the *next disc/item* and *previous disc/item* buttons.

④ Navigating Songs

After finding a playlist, artist, album, or genre navigate through the songs by using the *next/previous* track buttons.

Toyota Highlander stereo pictured may not be identical to your stereo and is shown only as an example